



Portable Power Trencher

Terratrencher Air Filtration

Air Pre Filter (Felt):

Fit this with the Stihl Name facing downwards:



Air Cleaner:

Fill the bottom lip of the air cleaner cartridge with grease to create a dust seal.



Oilable Foam Air Filter:

Lightly oil this foam filter and then squeeze dry with a rag. Should only be a VERY light coating of oil on foam. Remove plastic cap from carburetor intake and fit foam filter around alloy intake. (Hole is offset so take note of how it fits) Refit plastic cover over the foam filter carefully. Refit main filter.



*** IMPORTANT ***

Ensure the air filter cover is tightened as much as possible. This will ensure the air filter is squeezed tightly in the housing and will not allow dirt into the engine.

The internal foam air filter is basically an indicator for if dust is getting past the main air filter. If dust is present on the foam filter, investigate why there is dust getting through the air filtration system.

You may need to re-tune the power head a little leaner to compensate for the placement of the inner foam filter. Tune as required or contact Terratrencher Australia on 1800 665 932 to discuss the tuning. If your trencher was assembled by Terratrencher Australia we will tune the trencher prior to shipping to you.